



# TYRE REPAIR INSTRUCTION

## Instruction for replacement



**IF YOU GET A FLAT TYRE, THE TUBE CAN BE REPLACED WITHOUT REMOVING THE WHEEL.**



**This service kit contains:**

- Fitting instructions (below), tools are not required.
- Spare tube
- Mag wheel filler extension (in case filling hose has a snap-on connector)



- SAFETY!**
- ✓ Check the tyre filling station or pump is suitable for inflating small tyres.
  - ✓ Always wear appropriate PPE, including eye protection.
  - ✓ Never lean over the wheel hub when inflating a tyre.

### TUBE FITTING INSTRUCTION

- 1 Release the remaining air from punctured tyre.
- 2 Remove the red split ring.
- 3 Then remove the tyre & tube together (a)
- 4 Check that all sharp objects have been removed from the tyre.
- 5 Fit the new tube to tyre, before mounting on the hub.
- 6 Fit the split ring (b) **IMPORTANT!** *Make sure the split ring is properly fitted and the ring opening is exactly lined up with the tube inflator.*
- 7 Once the split ring is in place, inflate to approx. 5 PSI (33Kpa), double check tyre mounting and split ring before inflating to a max of 30 PSI (200Kpa).



**Remember, patch the old tube, or purchase an Original EXPRESSO tube as a spare. Don't use substitutes.**

Re-ORDER DETAILS	Part No.	Description
	K 880 0 301	TUBE
	880 0 221	TYRE BLACK